



USER GUIDE TELEVISION




FIBRE
ARGENTEUIL



Synchronization

Synchronizing the remote control with the decoder


1. Use your TV remote control to select the decoder's HDMI port in the "Sources" menu.
2. Point the new remote control at the set-top box.
3. Hold down the OK and APPS buttons simultaneously for 5 seconds. Release both keys. A screen will appear. Again, hold down the OK and APPS keys simultaneously for 5 seconds. Release both keys and a message will appear at the bottom of the screen indicating successful pairing.
4. Follow the instructions on the new screen. Click on start, and the device will detect the TV model. The TV's volume control and power buttons will synchronize.



Application button (**APPS**)



OK button





REMOTE CONTROL

Remote control



*Menu A and voice control

- **A button:** Opens the navigation menu at the bottom of your screen.
- **Voice Command:** Activates the Google Assistant to access the decoder's applications. It can only be used outside the Fibre Argenteuil environment. For more information, please visit assistant.google.com



Remote control functions for decoder control

1. Select TV input source.
2. Switch the TV on and off.
3. Activate voice command*.
4. Access application menu
5. OK button.
6. Exit menus.
7. Access Android TV main menu.
8. Adjust TV volume.
9. Mute volume.
10. Navigation menu
11. Search for content.
12. Parameter.
13. Navigate menu .
14. Access channel guide.
15. Return to previous channel.
16. Navigate channels.
17. Botton B
18. Botton C
19. Select a channel or enter text.
20. Activate / deactivate subtitles.

Quick technical support

Frequently encountered situations

- How do I get back to the Fibre Argenteuil guide? If you're using the applications on the Amino decoder, go to the “Application” tab at the top of the screen, then select the FibreArgenteuiltvguide logo to be redirected to the Argenteuil Fibre guide
- In the event of a return following a power outage, the decoder generally restarts faster than the router. This may result in an error message indicating that there is no Internet connection or that the decoder remains in standby mode. In this case, disconnect the power supply at the back of the decoder, then reconnect it.
- To solve sound problems, remember that every TV behaves differently. You can try connecting the HDMI cable to another port on your TV. Don't forget to change the source to match the port you've chosen.
- Regarding picture quality, if you've changed TV provider and are connecting a new set-top box to your TV, you may need to adjust the picture settings. Please refer to your TV set's instructions.
- The “OK” button, located in the center of the directional arrows, can sometimes be tricky to use. If you press this button for too long, a menu will open at the bottom of your TV instead of performing its main function, which is to confirm.





THANK YOU FOR CHOOSING US

If you have any questions, please don't
hesitate to contact us at 450-409-2012